

PLAY-BACK CONTROLS


1	Rewind ABC 2	Play/Pause DEF 3
Louder GHI 4	Back Up JKL 5	Advance MNO 6
Softer PRS 7	Slower TUV 8	Faster WXY 9
.	Listen/Replay Oper 0	Skip #

Press 3 to pause and 3 again to continue. Q=7 Z=9

AUDIX® Wallet Card
585-305-712, Issue 1, 10/92



AUDIX® Voice Messaging Wallet Card



ACTIVITY MENU

Record Messages (record, edit, address, file)	1
Get Messages (listen, reply/forward, save/delete)	ABC 2
Administer Greetings (record greetings/activate them for different call types)	DEF 3
Check Outgoing Messages (review, modify, resend, check files)	GHI 4
Change Password/Administer Lists (create, scan, modify lists)	JKL 5
Scan Messages Quickly (and/or headers)	PRS 7

BASIC COMMANDS

Help	'H
Restart at Activity Menu	'R
Wait	'W
Transfer out of system	'T
Look up name/ext. in Directory	**N
Exit system (hang up)	**X
Transfer call to operator	'O
Delete	'D
Undelete	**U
Hold message in category	**H
Relog in	**R

Use while addressing:

Alternate addressing (switch between name/ext.)	'A
Use group list	'L
Options Menu	'M